QUICK START GUIDE


FOLLOW THESE FOUR STEPS TO SETUP and ENJOY YOUR NEW CINIOS BACKYARD TV™

Note: Some A/V devices may not support all of the connection types shown. Cables shown are not provided.

CINIOS

CHOOSE A MOUNTING LOCATION

- Use a sturdy location to support the TV.
- For best picture quality, avoid direct sunlight on the screen:




CONNECT SOURCE DEVICE

(TV connectors are located under the cover on the back of the TV.)


BEST CONNECTION

HDMI




VERY GOOD CONNECTION

COMPONENT




GOOD CONNECTION

COMPOSITE




GOOD CONNECTION

S-VIDEO



BASIC CONNECTION

ANTENNA











3 CONNECT POWER





ONE-YEAR LIMITED PRODUCT WARRANTY ON PARTS AND LABOR

Parts and Labor

CINIOS INC. (the 'Company') provides a warranty to the original purchaser of the product against defects in materials and workmanship for a period of exactly one (1) year from the original date of purchase. For complete warranty terms and details, read the full statement in the User Manual or online at www.cinios.com/support.

Obtaining Warranty Service

To obtain warranty service you must first contact CINIOS Technical Support to receive a return authorization (at www.CINIOS.com). Proof of purchase in the form of a sales receipt, invoice, or copy specifying the original date of purchase <u>must</u> be presented within the warranty period to obtain service. Units must be sent to a CINIOS service center using prepaid freight in its original packaging.

Limitations and Exclusions

This one-year limited warranty only covers defects in materials and workmanship. Items not covered include but are not limited to: cosmetic damage,

normal wear and tear, commercial use, misuse, abuse, negligence, signal issues, power surges, connection to improper voltages, damage from shipping, acts of nature or war, any sort of customer misuse or operation for which is was not intended, improper installation or set-up, customer modifications, and repairs or adjustments by unauthorized service facilities. Units with unreadable, altered, or removed factory applied serial numbers, "image burn-in", or for routine maintenance are <u>not</u> covered. This warranty does not cover products sold "AS IS", "FACTORY RECERTIFIED", "REFURBISHED", or by a non-authorized reseller or retailer.

BOX CONTENTS:

- 1 Backyard TV w/integrated AC power cord
- 1 Remote Control w/Battery
- 1 Quick Start Guide
- 1 User Manual
- 4—Remote attach strips



CHOOSE SOURCE TO WATCH

- Press 'POWER' button on the remote or the TV side panel.
- Press 'TV/AV' button on the remote or 'SOURCE' on the TV side panel.
- Select the source to view that is connected from step 2.
- Press 'TV/AV' again to exit the onscreen display.

<u>For help or troubleshooting</u>, please refer to the User Manual or visit www.cinios.com/support page.

ENJOY YOUR NEW BACKYARD TV!

STORABLE REMOTE CONTROL:

- 1. Choose Velcro or magnet method.
- 2. Peel the backing from one Velcro piece, or one magnet strip.
- Press a Velcro strip on bottom of remote control and on side of the TV as shown below. Or press one magnet strip on bottom of remote control and hold firmly for several seconds.
- 4. Place the remote against the metal bezel anywhere for the magnet, or on the Velcro strip to never lose it again!
- 5. Save the extra Velcro and magnet strips for backup or a 2nd remote.



FCC NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

